

FIG. 1





FIG. 2

FIG. 3





FIG. 4



()

1




FIG. 6





FIG. 7



Downloaded from www.gettyimages.com

Figure 8 is a schematic diagram of a handheld electronic device, such as a calculator. The device features a display at the top and a keypad below it. The keypad includes several buttons: an up arrow button (802), a down arrow button (803), a plus button (804), a minus button (805), a delete button labeled "DEL" (806), and a maximum button labeled "MAX" (807). The device is shown in a perspective view, with a clip at the top for attachment to a surface.

[illegible]

FIG. 9






FIG. 10



11/17

FIG. 11



Copyright © 2000

FIG. 12




FIG. 13




FIG. 14





FIG. 15

FIG. 16




FIG. 17

